

# Test Your Satellite Phone Week – May 21-27, 2007

**Call 00-1-480-752-5105 to test your Iridium Satellite phone.**


“Test Your Satellite Phone” Week is a time for users to increase their knowledge of using their satellite phone and to confirm that it’s fully operational before an emergency strikes.

Iridium recommends users test their phones frequently. Follow the steps below to ensure operational success and ready-for-use status.

## Maintaining the phone:

---

- Keep your phone's battery charged.
- For maximum battery performance, allow the battery to discharge completely before fully re-charging.
- Make sure that the phone's SIM card is locked in place. Check this by removing the battery and ensuring that the SIM card tray is securely positioned.
- Protect the antenna by stowing it in the ‘down position’ when not in use.



## Testing the phone:

---

- Go outside with a clear view of the sky and horizon. Common obstructions such as tall buildings and nearby trees may cause calls to drop prematurely.
- Turn the phone on and ensure that the antenna is extended and rotated upwards, pointing straight up at the sky. Wait for the phone to register on the network – the LED indicator on top of the phone will be flashing green.
- To place a call dial 00, then country code, and then the phone number. Press the green 'OK' button to start the call. A phone number in the U.S. would be dialed 00-1-212-555-1212.
- To hang up a call, press the red 'C' button.
- To answer an incoming call, press the 'OK' button, and rotate and extend the antenna.
- You can receive text messages sent to your phone via the <http://messaging.iridium.com> website. The sender will need your Iridium number in order to address the message. To retrieve test message, press the 'Envelope' button, scroll to 'Received Messages' and press the 'OK' button to select.
- To retrieve voicemail messages, press the 'Envelope' button then press the 'OK' button to select 'Call Voicemail.' You will be prompted to enter your Iridium number followed by the star (\*) sign. You will then be prompted to enter your password. Your default password is the last seven digits of your phone number.

